The GNSS Settings screen is accessed from the GNSS Toolbar.



Sensor Configure

This will allow you to make changes to most of the settings in your <u>reference</u> or <u>rover profile</u>, including configuring the three tolerance modes, selecting the active tolerance mode, configuring the antenna height, configuring the auto-recording options and depending on the GNSS Sensor connected, the Electronic Bubble settings will be shown here as well. (The Model and Communication options cannot be configured while you are connected to your GNSS receiver.)

FieldGenius	5		- 🗆 X
GNSS	Profile		📩 😂 🤗
	Tolerance Setting: [Autonomous]	Ţ	Antenna Height
2	Tolerance Setting: [RTK Float]	A¶ □-⊡-∷	Auto Recording
3	Tolerance Setting: [RTK Fixed]	* •	Depth Sounder
	Active Tolerance: [Autonomous]		
		Close	

Depth Sounder

The Depth sounder option allows the program to connect by Bluetooth to a supported depth sounder sensor after you are connected to a GNSS receiver. The program supports the SonarMite BTX depth sounder and other depth sounders that support the NMEA depth sounder standard format .On the depth sounder set the port to Bluetooth and the Press to Setup button. Search and select the depth sounder Bluetooth device from the list and configure the Bluetooth connection per the manufacturers instructions (pin code may be required). Once you have selected the correct depth sounder Bluetooth device select Connect.

🤏 F	ïeldGenius	_		\times
De	epth Sounder			00
	Communication			^
	Port	Bluetooth		•
	Bluetooth Setup	Press to Setup		
	Bluetooth List	MINI 5	-	•
	Auto Connect			
	Device			
	Model	NMEA	-	•
	Units	Meter		
	Use Water Flevation			~
2	Connect	Close		

Once connected to the Depth Sounder you can select the auto reconnect option to reconnect to the sensor if communication is interrupted. With Bluetooth communication established you can select the device model as Sonarmite or NMEA depending on the type of depth sounder device you are using. The units of measure for the depth sounder are the same as the GNSS receiver. If the Use water level box is not checked than the height recorded by the program is a combination of the GNSS receiver position plus the antenna height and the depth sounder measurement. The antenna height needs to be input as the distance between the measure point on the GNSS Receiver and the measure point on the depth sounder. If the water level elevation is checked then the user needs to input the water level and the antenna height needs to be set as the distance from the

water surface to the measure point on the depth sounder. The GNSS receiver will record the horizontal location and the height will be the water level plus antenna height and depth sounder measurement.

De	epth So	ounder					
	Port		Blue	tooth			•
	Bluetooth Setup			F	Pre	ess to Setup	
	Bluetoot	h List	Μ	INI 5			▼
	Auto Cor	nnect	~				
	Device		_				
	Model		NN	1EA			-
	Units		Mete	r			
	Use Wate	er Elevation	\				
	Water El	evation	398.	300m			~
è		Disconnect	t	X		Close	

🎕 FieldGenius		– 🗆 X	
Antenna Height		<u></u>	
Model	User Defined	•	
Measured Height	1.500m		
Measure Point	GNSS and NMEA	Measure pts.	
Offsets			
Measure Point to ARP Offset - Horizontal		0.0mm	
Measure Point to ARP Offset - Vertical 0.0mm			
ARP to APC (L1) Offset - Vertical 0.0mm			
	ОК		

Sensor Information

The <u>Sensor Information</u> screen displays detailed information about the hardware you are connected to.

Sensor Information 🛁 🕮 😵				
GNSS Driver	GS14			
Hardware	GS14			
Serial Number	2810059			
System Version	6.13			
Measure Version	6.515			
Boot Version	6.06			
Battery	100%			
Battery Ext	None			
< >>				
\checkmark	ОК			

Link Configure

This turns on your GNSS Receiver's radio or modem to begin receiving RTK corrections, from either a base receiver or an NTRIP or GPRS server.

Li	nk Configure	🛁 😂 🔇	
	Device	^	
	Device Type	GSM Module 💌	
	Device Port	Internal 🗸	
	Device Setup	Press to Setup	
	Correction Data		
	Message Type	RTCM 3	
	Base Station ID	Any 💌	
	RTCM Transformat	tion	
1.	Fnahle		
(((1	Connect	Close	

Link Information

The Link Information screen displays detailed real-time information about the correction message being received by your receiver via a radio link from a base receiver, or via a cellular modem link from an NTRIP or GPRS server.

Link Information		?
Information		^
Data Age	1.0 sec	
Data Quality	100%	
Status	RTK corrections being received	
RTCM Transformation	Not Applicable.	
Reference		
Identification	1	
Latitude	N49°50'16.93114"	
Longitude	W119°36'36.29246"	
elline e tale la case	400.017	~
\checkmark	ОК	

Position Information

The <u>Position Information</u> screen displays detailed real-time information about your current position.

Position Information 📩 🛍 😵			
Latitude	N49°50'16.74805"		
Longitude	W119°36'35.51927"		
Ellipsoidal Height	387.265m		
Antenna Hgt (Meas)	2.000m		
Distance to Reference	Not Available		
Northing	5523884.777m		
Easting	312341.551m		
Elevation	387.265m		
Horz System	UTM83-11		
V C	Ellipsoidal (MIGS84)		
	OK		

Antenna Height

The <u>Antenna Height</u> screen allows you to configure the antenna height of your GNSS receiver.

Antenna Heigh	t)))))		
Model	GS14	•		
Measured Height	2.000m			
Measure Point	Bottom of antenna mour	nt 💌		
Offsets				
Measure Point to ARP Offset - Horizontal 0.0mm				
Measure Point to ARP Offset - Vertical 0.0mm				
ARP to APC (L1) Offset - Vertical 89.0mm				
	ОК			

Active Tolerance Mode

This button indicates which of the three tolerance modes setup in your Rover Profile is currently being used. Press this button to select the active tolerance mode. To configure the three tolerance modes, see the "Sensor Configure" button described above.

Selec	t Tolerance		<u>)</u> 🕄 🔇
		Autonomous	
		RTK Float	
		RTK Fixed	
X		Cancel	

Raw Data Logging

The <u>Raw Data Logging</u> screen is used to start and stop raw data logging on your GNSS reference or rover receiver, for later post-processing.

GNSS Raw	🗎 🕄 🛞	
File Name		Start Logging
Rate	1 Sec 🔹	
		View Files
Memory Total	956.8 MB	
Memory Free	893.2 MB	
X	Close	